

EMERGENCY GATE OPENING PROCEDURE

In the event of a power failure or system failure the vehicle gates can be opened and closed manually. **Do not attempt to force the gates open** as this will break the motor or gearing and require expensive repair.

The following procedure releases the gates from the motor arm and allows them to swing freely. It is simple and quick.

There is a tool in the post room sat on top of the mail boxes.



At the bottom of each gate there is a small flap covering a hexagon head.



Slide this to expose the head and apply the tool. A quarter turn releases the gate from the arm below.



The gate is now free to swing.



To return the gate to the motor arm simply locate the gate and turn back the head.